

Installation instructions for Dämmmatratzen

Before installation of the individual Dämmmatratzen is to ensure that the single mattresses **are dry and absolutely grease and oil free!**

Should individual mattresses may be contaminated they are no longer mounted!

- Laying Dämmmatratzen accordance Matt plan roughly to the object
- Bring mattresses with adequate pressure in shape and smooth
- Knock the insulation with light strokes if necessary
- It must be ensured that the Dämmmatratze resting completely
- The overlaps must be straight and narrow, the abutting edges close
- With hook closure is care taken to ensure that the binding wire Serves as a pure fixation wire rather than a pull wire
- Improper handling the hooks can tear
- At the closure technology with buckles, must Buckle in which always pull the tether entirely
be open to damage the tether to avoid
- The straps are used to fix the mattress elements and Not as drawstrings

When mounting, make sure to carry any sharp objects in the pockets, which could damage the surface of the Dämmmatratzen.

During commissioning of the object, it will come to the evaporation of the coating of the glass fabric from a temperature of 120 ° C. There is white smoke rising **health harmless**, for ca.15-20min. After that, the fabric is brownish color to white. This is an entirely normal process. Please adequately ventilated and any precautions (smoke alarm off).